

---

## Maintenance Guide for Wild River Timber Oiled Floors



In order to ensure long lasting satisfaction of your new Wild River Timber oil floor, it is important to correctly care for the floor starting immediately after installation. With the right care, the oiled floor will become increasingly easy to clean and more hard wearing over time.

### After-Installation Care

Although all wild River Timer floors comes factory oiled, we do recommend one (1) coat of Object Oil and buff right after installation and before the floor is used. As a result of this the surface will then be more hardwearing and be easier to clean and maintain in the future.

NOTE: This is optional

---

### Normal Cleaning

First dry dust or vacuum clean the floor.

Shake or stir the Wild River PNZ Wooden Floor Soap thoroughly for 2 minutes before use.

1. Fill a bucket with 5 L of (warm) rinse water. Fill another bucket with 5 L of (warm) water and add 50ml of Wild River PNZ Wooden Floor Soap. (If the floor is very dirty use 100ml of Wild River PNZ Wooden Floor Soap to 5 L of water)
2. Dip the mop (NO MICRO-FIBER) into the soap solution.
3. Wring half of the soap solution out of the mop.
4. Swish the damp mop across several square meters of floor. If certain parts of the floor are very dirty, use more soap solution, leave it to soak in or scrub the floor if necessary.
5. Rinse the mop in the clean rinse water and wring it out thoroughly.
6. Dip the mop into the soap solution again and wring it out until it is almost dry.
7. Mop up any dirt that has been loosened by the soap solution with the clean dry mop.

Rinse the mop in the rinse water again and repeat steps 2 to 7 until the whole floor has been cleaned.

**Never mop the floor with clean water after cleaning your floor with Wild River PNZ Wooden Floor Soap!**

Leave the floor to dry for approximately 15 minutes and avoid walking on the floor in the meantime.

