

Maintenance Guide for Wild River Timber Oiled Floors



Oiling & buffing your floor with Wild River PNZ Object oil

Please note! The room temperature should be between 16°C and 20°C.

Shake the Wild River PNZ Object oil thoroughly for 2 minutes before use.

1. Spray the Wild River PNZ Object oil onto the floor with a spray bottle and leave the oil to soak in.
2. Rub the Wild River PNZ Object oil into the wood with a clean dry white pad.
3. Then, using a lint-free cotton cloth, rub the floor until it is completely dry.

Leave the oil to dry. Avoid walking on the floor for the next 4 to 6 hours and make sure that the floor does not come into contact with water for the next 24 hours! The oil will continue to harden for the next week. Be careful when placing heavy objects on the floor and avoid dragging anything across the floor while the oil is hardening.

Clean the floor with Wild River PNZ wooden Floor Soap at least 24 hours to one week after applying the Wild River PNZ Object oil. This will help to prevent dirt being walked into the floor.

Machine Buffing

Your Wild River Timber floor dealer will be able to provide you with more information about applying the Wild River PNZ Object oil with a polishing machine or visit www.wildrivertimber.com.au and click on the video.

